

**6+**  
YEARS



#### CONTENTS

Handlebars  
and stem



Scooter deck and wheels

Tools Required:  
Allen key (Included)



#### ASSEMBLY

1. Slide the handlebar stem over the threaded locking section.
2. Ensure the arrow on the fork is facing forward and the handlebars sweep backwards.
3. Tighten the bolts evenly and tightly using the allen key provided.
4. Check the height of the steering system and make sure that the nuts are tightened and the handlebars and front wheel are perpendicular.
5. Make sure the wheel faces forward when the handlebars are held facing straight.

#### NOTE:

A bolt that seems fully tightened may require further turning after tightening the other three bolts.

#### ASSEMBLED

Please check all screws and fittings are secure before giving to a child. Ensure there are no broken components. Ensure all locking devices are engaged.

The item shall be used with caution, since it requires great skill, so as to avoid falls or collisions causing injury to the user and third parties.

**WARNING! Assembly must be completed by an Adult.**

If the tyre dose not feel firm, please inflate the tyre by pump. The maximum tyre pressure is 40psi. Recommended to inflate tyre to 35psi. Ensure tyres are firm but do not overinflate.



#### USE

Hold both handgrips firmly.  
Put one foot towards the front of the deck.  
With other foot, push off the ground to propel the scooter forward.  
Both feet can fit on the deck when desired speed has been reached.  
A brake is located at the rear, when necessary, press down on it to slow down.  
Press down gradually to prevent skidding or loss of stability.

## DIRT SCOOTER OWNERS MANUAL & ASSEMBLY INSTRUCTIONS

Thanks for your purchase this product. If any parts are missing or damaged, please contact one of our Customer Service Representatives by phone on

**1800-632-792 ( Australia)**

**0800-623-792 (New Zealand)**

via mail at [spares@hunterleisure.com.au](mailto:spares@hunterleisure.com.au)

visit [www.momentumservicesco.com](http://www.momentumservicesco.com)

**Hunter Leisure Pty Ltd.**

94 Keilor Park Drive Tullamarine, 3043, Victoria, Australia

#### **A GUIDE TO SAFE SCOOTERING:**

1. We recommend this scooter is for pavement use only. It is dangerous to ride on a public highway.
2. Do not ride at night or in the dark. Visibility is often limited at dawn and dusk.
3. Always give pedestrians right-of way, and don't ride too close to them.  
Never park your scooter where it can cause a nuisance.
4. Avoid hazards that may cause you to lose control of your scooter such as pot holes, uneven pavements and manhole covers.
5. Leave plenty of room when passing parked vehicles and watch out for doors being opened in your path.
6. Remember that braking distance should be increased in wet weather, and regular checks of brake, steering should be made.
7. Never carry passengers on your scooter.  
Never carry packages in your hands while scootering, or fix anything to your scooter that could obstruct your visibility or control.
8. Don't wear anything that restricts your hearing.
9. Always ride with both hands on the handlebars.
10. Don't wear very loose clothing, which could hang down and become caught in the wheels.
11. We recommend that light-coloured or fluorescent clothing be worn which helps others to see you in daylight and poor light.
12. Shoes are mandatory and we strongly recommend wearing pants and long sleeve shirts to avoid injury if you fall.  
Gloves and eye protection also makes good sense.  
Cover your handlebars, stem and top tube with safety pads for extra protection.
13. If tyres are worn, please replace them.

Wheel bearings: avoid going through water, oil or sand as this can damage wheel bearings.

To look after the wheel bearings, systematically check that the wheels turn properly by turning the scooter upside-down and using your hand to spin the wheels. If the wheels do not spin they must then be removed to check their condition. First unscrew the wheel axle, remove the axle and detach the wheel, then carefully push the two wheel bearings out of their housing. If they are chipped or dented, new ones should be bought. If there is no visible damage, they must then be oiled. To do this, remove all traces of grease, mud or dust with a kitchen towel or cloth, and re-oil them with a grease spray or by leaving them to soak overnight in oil [turn them several times in the oil first]. Then reassemble the wheel bearings and axles, followed by the wheel, onto the scooter. Proceed in the same manner for the other wheel.

Wheels: the wheels wear down with time and can be pierced if overly used on rough surfaces. The back wheel on which the brake is applied is particularly affected after several hours of braking. In the interests of safety, they should be checked regularly and changed if necessary.

#### **IMPORTANT:**

We recommend you to save all packaging material until assembly is completed.  
Please retain this manual for future reference.

#### **WARNINGS:**

Warning: Read the information supplied by the manufacturer.

Protective equipment should be worn consisting of wrist protectors, gloves, knee pads, helmets and elbow pads. User's maximum weight 100kg.

The braking mechanism to reduce speed will get hot from continuous use, do not touch after braking.  
Keep fingers away from moving parts to avoid pinching and entrapment.

#### **SAFETY ADVICE:**

This is a two wheel self propelled scooter designed for a single rider only.

It is not intended or equipped for road use, off road use or use with any motorised device.

Use on flat, clean and dry surfaces, where possible keep away from other road users.

Please add oil for lubrication periodically and replace bearing when its worn.

Use a few drops of light machine oil to lubricate wheel bearing. Clean bearing after use.

Regular maintenance enhances the safety of the equipment.

#### **NOTE:**

Scooter should never be ridden by more than one person at a time.

Never ride at night, check local laws regarding scooter use and obey all traffic and pedestrian regulations, and give right of way to pedestrians.

Care should be taken when riding on wet pavements as braking action and wheel traction may be reduced.  
Never leave your scooter unattended.

Do not modify the scooter or change the scooter in anyway not outlined in these instructions.

Self locking nuts and fixings may lose effectiveness over time so please check and tighten periodically.

#### **FOR YOUR CHILD'S SAFETY:**

Recheck that all screws, nuts and bolts are firmly tightened.

Make sure that your child is capable of riding this scooter.

Do not allow your child to ride unsupervised.