


Folding Bicycle Supplementary Manual

Unfold the Main Frame

- Standing on the chain side of the bike, swing the front and rear sections of the bike apart.



- The spring loaded bolt on the rear section (1) should clip into the front section (2)



- Rotate the quick release lever into the correct position and push it down to lock firmly into position. Ensure the lever is locked down in correct position, so the word "open" is pointing away from the clamp

Handlebar and Stem Assembly

This folding bicycle is equipped with a handle bar system that can be folded. Please read below, on how to unfold and assemble your bicycle for the first time.

Unfold the Handlebars and secure the handlebar lock



1. Rotate the handlebars up into correct position
2. While holding handlebars in correct position, tighten the locking mechanism.



WARNING: Please ensure you check the tightness of the lock knob before every use on the bicycle. If this clamp is not tight enough it may cause the handlebars to become loose and have no control over the bicycle.